Mitchell
ARMS

OWNER'S MANUAL

Congratulations . . . on your purchase of the AK-22 Semi-Automatic or 22 Magnum Rifle; a design inspired by the AK-47 Centerfire rifle. This is a novel rifle to own and use. It's form and function is flawless.

The rifle is made in Caliber 22LR/22 Magnum which allows very inexpensive shooting enjoyment. You will find your rifle to be extremely accurate and reliable.

MITCHELL ARMS, INC.
3400 W. MacArthur Blvd., Suite I, Santa Ana, CA 92704
Phone: 714/957-5711 TELEX 880126 FAX 714/957-5732

Your rifle is as safe as we know how to make it, but you must use good sense and caution; as you must with any gun.

Some Key Safety Rules Are:

1. Treat every gun as though it were loaded, even if you **know** it isn't!
2. Keep the barrel pointed in a safe direction always.
3. Never load the rifle or the magazine until you are ready to shoot; and then only in a place you know is safe.
4. Always keep the barrel pointed "down-range" even when you know it's empty.
5. Always be certain of your target and the target back-stop before shooting.
6. Have fun; just follow these rules and use common sense in handling this or any other gun.

Safety & Handling/Care & Use

Your rifle has a large safety lever on the right side of the receiver which can be moved up or down only, but it performs three functions depending on where you place it.

1. In the full up position the trigger is blocked internally and the bolt cannot be moved in any direction. The rifle is deemed to be "on safe". **Even so**, keep the rifle pointed in a safe direction always and treat it like it was loaded. Don't pull or "test" the trigger while it's "on safe" as you can stress the action parts or even break them if you are strong enough.

2. Notice that there is a notched section in the safety lever. This allows you to pull the bolt back and move the safety lever upward to engage the bolt at the charging handle. This position allows you to see into the breech and is the position always to be used in cleaning your rifle.

3. Moving the safety lever full down puts your rifle in firing condition. Make certain you know your target; use good sense and have fun. When finished, pull the bolt back and lock it back in the notch in the safety lever.

Your rifle is well made and requires only normal care and cleaning. Keep the rifle lightly oiled, both inside and out. Don't over oil it, but do keep a light coating of oil all over it.

You can clean/oil the inside of your rifle by just removing the upper cover on the top of the receiver. Just push forward on the protruding latch in the top rear of the cover; it is spring loaded. This will allow you to lift off the cover and it will expose the internal mechanism for cleaning.

Accessories available for your AK-22

Spare 20 round magazines - 22LR
Spare 10 round magazines - 22 Magnum
Scope mount
Sling

Spare parts and product service are readily available for your rifle. Use the schematic drawing on the back to identify any parts you may need and order by using both part name and number please.

MITCHELL ARMS, INC.
3400 West MacArthur Blvd., Suite I
Santa Ana, California 92704
Phone: 714/957-5711 TELEX 880126 FAX 714/957-5732

PART NO.	PART NAME	PRICE
1	Butt Plate Screw	.39
2	Butt Plate	3.25
3	Stock	24.95
4	Grip Screw	.79
5	Washer	.20
6	Rear Link Screws	.39
7	Recoil Spring Support	7.95
8	Limiting Device	3.95
9	Recoil Spring Stop Ring	.39
10	Hammer Spring Holding Pin	3.95
11	Hammer Spring Guide	3.95
12	Scope Mount Filler Screws	.25
13	Recoil Spring Guide	3.95
14	Recoil Spring	2.50
15	Upper Cover	14.95
16	Bolt	29.95
17	Recoil Spring Guide Bushing	.79
18	Extractor	2.49
19	Extractor Pin	.39
20	Extractor Spring	.39
21	Cocking Lever	5.50
22	Cocking Lever Catch Pin	.39
23	Firing Pin Spring	.39
24	Striker	1.18
25	Striker Pin	.39
26	Rear Sight Blade	6.25
27	Rear Sight Adjust Screws	1.20
28	Rear Sight Elevator	2.59
29	Rear Sight Base	5.59
30	Rear Sight Pin	.39
31	Rear Sight Spring	.39
32/34	Upper Handguard Catch	1.59
33	Handguard Catch Ring	.39
35/36/37	Front Handguard Holder Upper	7.95
38	Upper Handguard Spring	1.49
39/40/41	Upper Handguard Support	9.95
42	F/Sight Ramp and Hood	13.75
43	F/Sight	.79
44	F/Sight Stop Screw	.35
45	F/Sight Ramp Stop Screw	.35
46	Barrel Cap	2.50
47	F/Sight Ramp & Hood Pin	.39
48	Barrel	44.95
49	Cleaning Rod	3.95
50	Lower Hand Guard Support	5.95
51	Lower Hand Guard	19.95

PART NO	PART NAME	PRICE
52	Cleaning Rod Spring	.79
53	Barrel Catch Screws	.39
54	Cover Catch Pin	.39
55	Frame	NOT SOLD
56	Frame Cover Catch Screw	.39
57	Magazine Catch	1.75
58	Magazine Catch Spring	.39
59	Magazine Catch Pin	.39
60	Ejector	3.25
61	Ejector Spring	.39
62	Ejector Pin	.39
63	Sear Spring	1.59
64	Sear	6.50
65	Sear Pin	1.25
66	Sear Spacer	.39
67	Trigger Guard Pin	.39
68	Hammer	12.50
69	Hammer Pin	1.20
70	Hammer Spring	.79
71	Sear Lever	3.95
72	Sear Lever Pin	.79
73	Trigger	5.95
74	Trigger Pin	.39
75/77	Safety	5.75
76	Safety Holding Ring	.39
78	Safety Screw	.39
79	Grip	9.95
80	Trigger Spring	.79
81	Trigger Spring Pin	.39
82	Frame Cover	NOT SOLD
83	Trigger Guard	5.95
84	Rear Link	3.19
85	Magazine Follower	3.19
86	Long Magazine Box	9.95
87	Long Magazine Spring	3.19
88	Magazine Spring Guide Pin	.79
89	Short Magazine Box Base	.79
90	Short Magazine Box	6.50
91	Short Magazine Spring	3.19
92	Stock Setscrew Wrench	2.50
93	F/Sight Adjust Tool	3.25
94	F/Sight Setscrew Wrench	1.20
95	Sling	4.95
96	Sling Buckle	.79
97	AK Long Magazine Body	17.95
98	AK Long Magazine Base	.89



Mitchell
ARMS